







cornilleau

SPORT 340

INDOOR & OUTDOOR



Réf 133400

Indoor Bleu / Blue / Blau / Blauw / Blu / Azul

Réf 133405

Outdoor Bleu / Blue / Blau / Blauw / Blu / Azul

F

Notice de montage et d'utilisation

Document à conserver

GB

Assembly and operating instructions

Please keep for future reference

D

Benutzung und Montageanleitung

Das Document ist aufzubewahren

NL

Gebruik en montage aawijzingen

Goed bewaren

I

Istruzioni di montaggio e di utilizzo

Documento da conservare

SP

Instrucciones de montaje y de utilizacion

Documento a conservar

CONTENU DU COLIS










THIS BOX CONTAINS

INHALT DES PAKETS

INHOUD VAN DE DOOS


CONTENUTO DEL CARTONE


CONTENIDO DEL PAQUETE



2700


<p>1121X4</p> <p>Ø8 1121 x4</p>	<p>1288X4</p> <p>Ø6x15x6 1288 x4</p>
<p>1033X4</p> <p>Ø8x80 1033 x4</p>	<p>1830X4</p> <p>Ø6x35 1830 x4</p>
<p>1140X4</p> <p>Ø6 1140 x4</p>	<p>1296X4</p> <p>Ø6x15x21 1296 x4</p>
<p>1838X4</p> <p>Ø6x80 1838 x4</p>	<p>1510X8</p> <p>Ø6x40 1510 x8</p>
<p>1120X12</p> <p>Ø6 1120 x12</p>	<p>1711X2</p> <p>Ø6x45 1711 x2</p>
<p>2343X1</p> <p>2343 x1</p>	<p>1836X4</p> <p>Ø6x70 1836 x4</p>



MONTAGE**ASSEMBLY****MONTAGE****MONTAGE****MONTAGGIO****MONTAJE**

Montage de toutes les phases à 2 personnes.
 Assembly during all stages with 2 people.
 Für die Montage sind 2 Personen von Vorteil.

Montage van alle fasen met 2 personen.
 Il montaggio richiede 2 persone in tutte le fasi.
 Montaje de todas las fases a 2 personas.







Laisser du jeu
 Leave a little play
 Es ist ein Spiel zu lassen

Laat wat speling
 Lasciare del gioco
 Dejar holgura



Repetir l'opération (x) fois
 Repeat operation (x) times
 Wiederholen Sie diesen Vorgang (x) mal



Deze handeling (x) maal herhalen
 Operazione da ripetere (x) volte
 Repetir la operacion (x) veces



5 x2




2343





4


3




5



7





6





4		Ø6 1120
4		Ø6x15x21 1296
4		Ø6x35 1830



2343








REPARATION (UNIQUEMENT SI NÉCESSAIRE)	EMERGENCY REPAIR	ZUM ÖFFNEN (NUR FÜR ERSATZ)
REPARATIE (ALEEN INDIEN)	RIPARE (SOLO SE NECESSARIO)	REPARACIÒN (SOLAMENTE SI ES NECESARIO)

INDOOR

OUTDOOR



sport 340

Réf 133400 Indoor Bleu / Blue / Blau / Blauw / Blu / Azul

Réf 133405 Outdoor Bleu / Blue / Blau / Blauw / Blu / Azul

NOMENCLATURE DES PIÈCES DÉTACHÉES	SPARE PARTS LIST	VERZEICHNIS DER ERSATZTEILE
LIJST VAN ONDERDELEN	NOMENCLATURA DEI PEZZI DI RICAMBIO	NOMENCLATURA DE LAS PIEZAS DE RECAMBIO

INDOOR BLEU PL133400/1
OUTDOOR BLEU PL133405/1

